





### Overview of OpenManage Enterprise

Dell EMC OpenManage Enterprise is an intuitive infrastructure management console. It is **designed to take the complexity out of IT infrastructure management**. It delivers better results with less time and fewer steps. OpenManage Enterprise helps IT professionals balance time and energy between complex IT infrastructure and business goals.

<p><b>SIMPLIFY</b></p>  <p>Robust, intuitive, management capabilities, regardless of form-factor</p>	<p><b>UNIFY</b></p>  <p>One-to-many management from a single console: built for scale</p>	<p><b>AUTOMATE</b></p>  <p>Automated IT processes for greater efficiency</p>	<p><b>SECURE</b></p>  <p>Design for security throughout the infrastructure lifecycle</p>
---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------

### License advantages

- Perpetual license – purchase once for software life time
- No additional support subscription required – OpenManage Enterprise support is attached to your PowerEdge ProSupport contract
- License cost is the same regardless of form factors (rack, blade, or tower)
- Monitor and create alerts for 3rd party devices at no additional cost

### OpenManage Enterprise License Types

Pre-requisite: iDRAC Express or iDRAC Enterprise

Download at: <https://marketing.dell.com/en/OpenManageEnterprise>

License	Description	Licensing model	Pricing
OpenManage Enterprise Base version	Basic management and monitoring for Dell EMC PowerEdge Servers and 3rd party devices	NA	Free - delivered as part of the Dell EMC PowerEdge value
OpenManage Enterprise Advanced License (includes Power Manager plugin)	All base features plus, advanced infrastructure automation, management and monitoring for Dell EMC PowerEdge Servers	Perpetual	\$299/Server for new customers; \$200/Server for upgrade from Server Config license

### Please note – licenses discontinued:

OpenManage Enterprise Server Configuration Management license is discontinued as of June 2019. Existing server configuration license customers, will still be able to use the server configuration features without upgrading. However, we highly encourage customers to upgrade. The advanced license will provide access to future enhancements.

Although an official end-of-life (EOL) date has not been determined, OpenManage Essentials Base version and OpenManage Essentials Server Configuration license are no longer being actively improved. Customers are highly encouraged to upgrade to OpenManage Enterprise Base version or OpenManage Enterprise Advanced license. If you have any questions, please contact Dell.

## Why upgrade to OpenManage Enterprise Advanced license:

### Benefits in the advanced license:


- **Consolidated power management:** Dell EMC OpenManage Enterprise Power Manager is included in the advanced license. The Power Manager plugin can be easily installed and enables streamlined power management through the OpenManage Enterprise console
- **Automated deployment:** Deploy PowerEdge servers automatically with service tags or node IDs
- **Enhanced modular management:** Capture and edit chassis templates using the intuitive OpenManage Enterprise user interface
- **Configuration and drift detection:** Create firmware and configuration baselines for compliance monitoring and enable automated updates on your schedule

For more information, please download our [solution brief](#)

Visit [technical support site](#) for user guide and other additional documents

Current license	Upgrade license	Base features	Server Config features*	Advanced features (incl. Power Manager)
New Customers	OpenManage Enterprise base 3.2 <b>Free</b>	✓		Disabled
	OpenManage Enterprise 3.2 advanced license <b>\$299/server</b>	✓		✓
OpenManage Enterprise 3.1 or OpenManage Essentials <b>base</b>	OpenManage Enterprise 3.2 base <b>Free</b>	✓		Disabled
	OpenManage Enterprise 3.2 advanced license <b>\$299/server</b>	✓		✓
OpenManage Enterprise 3.1 or OpenManage Essentials with <b>server config license</b>	Upgrade to OpenManage Enterprise 3.2 base <b>Free</b>	✓	✓ *	Disabled
	Upgrade to OpenManage Enterprise 3.2 advanced license <b>\$200/server</b>	✓	✓ *	✓

\* Please note, OpenManage Enterprise server configuration management license discontinued. However, Server configuration features will remain available for existing customers.



[Learn more](#) about Dell EMC OpenManage Enterprise



[Contact](#) a Dell EMC Expert



[View more](#) resources



Join the conversation with #HashTag